

ATTACH WALL CABINET TO WALL CLEATS  
USING INSTALLER SUPPLIED SCREWS  
USE BEAUTY FINISH WASHERS ( SUPPLIED )  
AT ALL 4-CORNERS  
NO FURTHER THAN 1" X 1" OUT OF CORNERS

FASTEN 3/4" x 3 1/2"  
CLEAT TO WALL

UPPER CABINET

3/4" THK X 4" HT

LAMINATED SET-ON BACKSPLASH

FILLER STRIPS SHIPPED 5-3/4" WIDE  
SCRIBE FILLER TO ADJACENT WALL  
CABINET ELEVATION SHOWS FILLER WIDTH  
ATTACH TO CABINET BOX SIDE  
ATTACH WITH SCREW FROM INSIDE CABINET BOX

ATTACH BASE CABINET  
W/ SCREWS AT TOP  
LEFT & RIGHT CORNERS

BASE CABINET

DETACHED  
TOEKICK

SHIM LEVEL  
SCREW TO WALL

